

# PARTS LIST

for

# KitchenAid®

## REFRIGERATOR

### MODEL KSSS42DWX02

SS-Stainless Steel




FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS



# CABINET PARTS


For Model: KSSS42DWX02



1		Cabinet (Not A Serviceable Part)
2	1112019	Leveler, Front (2)
3	1113249	Retainer (2)
4	1112023	Roller, Front & Rear (4)
5	1112695	Leveler, Adjustable (2)
6	1112936	Adjusting Rod (2)
7	1113250	Sleeve, Retainer (2)
8	1112937	Bushing, Rod (2)
9	2000489	Screw, 10-32 x 5/8
10	1112939	Hole Plug, Leveler
11	1112849	Cap, Grommet
12	1112970	Grommet, Water Tube
13	1113122	Grommet, Wiring
14	2000613	Wiring Harness, Cabinet
15	1112848	Drain Fitting
16		Gap, Cover Assembly (Top)
	2001199	Left Side
	2001200	Right Side
17	1112906	Shoulder Screw
18		Hinge (Top)
	1112901	Left Side
	1112912	Right Side
19	1112988	Shim, Hinge Top (4)
20	1112805	Guard, Wiring
21	1112907	Door Closer, Fixed Cam
22	487818	Screw, 8-32 x 5/16
23	1112992	Door Closer Assembly (2)
24		Bracket, Door Closer
	1112947	Left Side
	1112948	Right Side
25	486194	Screw, 8 x 1/2
26	1112973	Tap Plate, Hinge Butt (2)
27	1113227	Fastener (3)
28		Gap, Cover Assembly (Bottom)
	2001200	Left Side
	2001199	Right Side
29		Hinge (Bottom)
	1112919	Left Side
	1112923	Right Side
30		Shim, Hinge Bottom
	1112942	1 Each
	1112943	2 Each
31	2000490	Screw (4) 1/4-28 x 3/4
32	1113809	Spacer Lower Door Hinge
34	1112138	Grille Base, Front
33	1105408	Hole Seal
35	489238	Screw (6)
36	1112835	Cover, Rear
37	1113123	Grommet, Wiring
38	1113079	Grommet, Flexible
39	1112926	Grommet, Tube
40	487534	Screw, 8 x 3/4

# CABINET TRIMS AND BREAKER TRIM PARTS


For Model: KSSS42DWX02



1	1112676	Breaker Trim, (One Piece)
2	1113277	Retainer Side (4)
3	1112690	Retainer Trim Freezer (2)
4	1112686	Retainer Trim Refrigerator (2)
5	1112682	Magnet, Side (4)
6	1112684	Magnet, Freezer (2)
7	1112680	Magnet, Refrigerator (2)
8	1112711	Heater, Mullion
9	1113836	Trim (R.S.)
10	1113835	Trim (L.S.)
11	489238	Screw (12)
	487246	Screw (Repair)
12	1112801	Trim (Bottom)
13	488649	Screw, 8-32 x 1/2 (8)
14	1113843	Spacer Trim, Grille
15	1113604	Retainer, Unit Base (2)
16	487944	Washer (2)

# REFRIGERATOR LINER PARTS


For Model: KSSS42DWX02



1		LINER (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
3	843436	Grommet, Screw (3)
4	842339	Grommet
5	1112115	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw, 8 x 1-1/4 (8)
8	486194	Screw, 8 x 1/2
9	1112257	Hole Plug
10	2000951	Cover, Liner Back
11	1112219	Control Panel Assembly (Meat)
12	1112134	Insulation, Liner Back Cover
13	1112132	Duct, Meat Pan
14	1112218	Damper Control, Meat Pan
15	1112258	Control Knob, Meat Pan
16	837444	Retainer, Knob
17	1112789	Bracket, Light
18	1112613	Socket, Light
19	547225	Light Bulb
20	1112994	Wiring Harness, Air Baffle
21	1112709	Wiring Harness, Light Socket
22	1116793	Cover, Thermistor
23	1116959	Thermistor
24	2000530	Flexible Grommet
25	1112788	Shield, Light
26	2000527	Guard, Air Return

# FREEZER LINER PARTS

For Model: KSSS42DWX02






1		Liner (Not A Serviceable Part)
6	538533	Support Clip, Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw, 10-12 x 3/8 (2)
9	992720	Stud, Support (4)
11		Rail, Evaporator Cover
	2000956	Left Side
	2000957	Right Side
12	486194	Screw, 8 x 1/2
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
15	842339	Grommet (15)
16	1112260	Support, Evaporator
17	658944	Stud, Shelf (20)
18	487559	Screw, 8-15 x 1-1/4 (20)
19	1112843	Gasket, Evaporator Cover (2)

# ICE CONTAINER PARTS


For Model: KSSS42DWX02



1		Spacer, Track
	1112282	Left Side
	1112281	Right Side
2	1113870	Roller
3	1113871	Eyelet, Roller
5	1113169	Stop, Roller
6	488307	Washer
7	486194	Screw, 8 x 1/2
8	1113126	Bracket, Motor
9	1113960	Motor Assembly
10	488906	Screw, 8-32 x 5/16
11	983663	Coupling, Motor
12	1112613	Socket, Light
13	1113129	Cover, Motor
14	487294	Screw, 8-32 x 3/8
15	1112286	Ice Container
16	1112378	Conveyor
17	983668	Coupling, Conveyor
18	946192	Drive Bar, Drum
19	946195	Bearing Nut
20	946193	Drum
21	946194	Baffle
22	2001034	Overlay, Cover
23	1112381	Front Cover
24	488886	Screw, 8-18 x 1/2 (5)
25	489211	Screw, 10-16 x 3/4
28	1113140	Lens, Dispenser
29	547225	Light Bulb

# REFRIGERATOR CONTROL PANEL PARTS


For Model: KSSS42DWX02



1	1112641	Control Panel
2	2000975	Inlay, Control Panel
3	1113390	Circuit Board
4	1116853	Control Knob
5	837444	Retainer, Knob
6	1108112	Switch, Rocker Arm
7	1113135	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113774	Shield, Control Panel
11	1112613	Socket, Light (2)
12	547225	Light Bulb (2)
13	486194	Screw, 8 x 1/2
15	1112708	Channel, Wiring
16	1115375	Clip, Wiring (2)

# FREEZER CONTROL PANEL PARTS


For Model: KSSS42DWX02



1	1112596	Control Panel
2	1113964	Inlay, Control Panel
3	1113466	Thermostat & Barrier Assembly
4	488974	Screw (2)
5	851387	Switch, Rocker Arm (Dispenser Motor)
6	1113134	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113768	Shield, Control Panel
11	1112613	Socket, Light
12	486194	Screw, 8 x 1/2
13	547225	Light Bulb
14	1112707	Channel, Wiring
15	1108112	Switch, Rocker Arm (Light)
16	1112592	Knob, Thermostat
17	1115375	Clip, Wiring

# REFRIGERATOR SHELF PARTS


For Model: KSSS42DWX02





1	1113543	Frame, Shelf
2	1112318	Glass, Shelf
3	1113547	Reflector, Shelf
4	1113791	Gasket, Glass (2)
5	1125913	Wine & Egg Rack
7	1113551	Frame Assembly
9	1113894	Cover, Crisper
10	2000155	Glass, Crisper
14	2000888	Crisper Pan
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw, 10-16 x 3/4
18	488307	Washer
19	2000892	Utility Pan
20	2000896	Meat Pan
25	1112165	Crisper Spacer, Right Side (2)
27	1113169	Stop, Roller
28	1113890	Crisper Spacer, Left Side (2)
29	486194	Screw, 8 x 1/2


## FREEZER SHELF PARTS



1	1112366	Solid Shelf
2	2000886	Front, Ice Compartment
3	1113565	Shelf, Bottom (2)
	1113637	Shelf, Top (1)
4	1113640	Basket (2)
5	1113643	Trim, Basket
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw, 10-16 x 3/4
18	488307	Washer
22	2000061	Slide, Basket R.S.
	2000062	Slide, Basket L.S.
24	1113169	Stop, Roller
25	486194	Screw, 8 x 1/2

# REFRIGERATOR DOOR PARTS


For Model: KSSS42DWX02



1	2000573	Door Panel, Refrigerator (Also Order Item 29)
2	939101	Screw Anchor (8)
3	1112945	Hinge Assembly, Top
4	1112940	Spacer
5	489282	Screw
6	1112921	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112541	Gasket Retainer, Top & Bottom
9	2000446	Door Gasket, Magnetic
10	489101	Screw, 7 x 1/2 (36)
11	2000182	Handle, Door
15	487052	Screw, 8-15 x 1/2
16	2000082	Trim (Top)
17	489112	Screw, 6-32 x 1/2
18	1113820	Trim (Side)
19	2000088	Trim (Bottom)
20	1113953	Panel, Interior Door
21	1113951	Ladder, Shelf (2)
22	1112530	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw, 8 x 1/2
25	1112721	Bin, Utility
26	1112736	Door, Utility Bin
27	2000912	Door Shelf (4)
28	1125936	Butter Tray
29	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)

# FREEZER DOOR PARTS


For Model: KSSS42DWX02



1	2000599	Exterior Door Panel, Freezer (Also Order Item 4)
2	1112997	Tube, Wiring
3	1112928	Retainer, Tube
4	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)
5	1112978	Insulation, Dispenser
6	1112916	Hinge, Bottom
7	489282	Screw
8	1112944	Hinge, Top
9	1112940	Spacer Plate Expansion (2)
10	2001032	Overlay, Shelf
11	1112488	Wiring Harness,
10	2001032	Overlay, Shelf Freezer Door
12	1112533	Gasket Retainer, Side (2)
13	1112540	Gasket Retainer, Top & Bottom
14	2000445	Door Gasket, Magnetic
15	489101	Screw, 7 x 1/2 (34)
16	2000182	Handle, Door
20	487052	Screw, 8-15 x 1/2
21	2000078	Trim (Top)
22	489112	Screw, 6-32 x 1/2
23	2000085	Trim (Bottom)
24	1113820	Trim (Side)
26	1113946	Panel, Interior Door
28	1112766	Door Shelf, Outer Trim
29	1112771	Door Shelf, Inner Trim
31	1112763	Support, Trim Ends
32	227991	Wire Connector
33	939101	Screw Anchor
34	1112554	Ice Chute

# DISPENSER AND FRONT PARTS

For Model: KSSS42DWX02






1	1107943	Housing, Dispenser
2	987049	Bracket, Water Fitting
3	2155037	Water Fitting, Dispenser
4	487916	Screw, 8 x 3/8
5	987053	Water Tube
6	841707	Insert, Tube
7	488878	Clamp, Tube
8	488886	Screw, 8-18 x 1/2
9	488316	Screw, 8-18 x 3/4
10	987048	Grommet
11	2149097	Heater, Ice Dispenser
12	2147167	Ice Door Mechanism
15	2147168	Ice Door
16	489000	Screw, 9-12 x 1/2
17	1127421	Lever, Ice Dispenser
19	987917	Bearing, Clip
20	1115349	Lever, Water Dispenser
21	488307	Washer
22	983696	Spring, Lever
23	983697	Bearing, Lever
24	1120581	Delay Mechanism
25	1107454	Bracket, Control
26	841336	Switch
27	984683	Insulation, Switch
28	488361	Screw, 4-40 x 1
29	987265	Lamp Holder
30	488500	Screw, 8-32 x 3/8
31	851386	Light Switch
32	1107457	Plunger, Extension
33	983986	Spring, Plunger
34	983987	Retainer, Pin
35	934302	Wiring Harness, Door
36	984494	Wiring Shield
37	1118269	Guiding, Ice
38	1119056	Glass Top
39	489197	Screw
40	487052	Screw, 8-15 x 1/2 (6)
41	851389	Light Bulb
42	1112889	Front Cover, Housing
43	1129333	Shroud
44	1112836	Cover, Dispenser Opening
45	2000068	Trim, Front (2)
46	487052	Screw, 8-15 x 1/2
47	983900	Grille, Overflow
48	934316	Switch
49	1113382	Overlay, Cover
50	489098	Union
51	487857	Nut-Ball Sleeve
52	488794	"O" Ring Seal
53	487944	Washer (2)
54	488568	Screw (2)
55	482672	Seal
56	488366	Tube, Clamp
57	486194	Screw

# UPPER UNIT PARTS

For Model: KSSS42DWX02



1	1113005	Assembly, Unit Base
2	1113386	Assembly, Sound Barrier
3	4210577	Compressor (Includes Items 8, 9, 10 & 11) (Also Order 876765 Tube Kit)
4	1105220	Bracket, Mounting
5	1105219	Grommet, Bracket
6	1105200	Grommet, Mounting
7	489334	Screw
8	2001232	Overload
	1113273	For Service Compressor Only
9	1105221	Terminal Cover
10	1105222	Strap, Cover
11	1108066	Relay
12	1118576	Running Capacitor
13	1108065	Starting Capacitor
14	1108033	Clamp
15	487869	Screw, 8 x 3/8
16	1113015	Condenser
17	943447	Grommet (4)
18	1113019	Clamp (4)
19	487522	Screw, 8-32 x 5/8 (4)
20	1113228	Wire Tie (2)
21	1108023	Drier
22	1113083	Mounting Bracket, Motor
23	1113081	Motor, Fan
24	1113082	Blade, Fan
25	2000190	Orifice, Fan
26	1113303	Gasket, Orifice
27	488130	Nut (3)
28	489084	Screw, 8 x 1/2 (3)
29	486692	Speed Nut
30	1127570	Defrost Timer (10 Hour)
31	488911	Screw, 6-20 x 3/8
33	1113066	Clamp, Tube (2)
34	489348	Clamp, Nylon
	1113067	Clamp, Tube
	488888	Clamp, Tube
35	486194	Screw, 8 x 1/2
36	1113075	Cover, Fan
37	1113028	Cover, Condenser
38	1113076	Extension, Housing
39	937360	Service Cord
40	489368	Screw (3)
41	1113162	Clamp, Cord (2)
42	1113229	Switch, Power Disconnect
43	488879	Screw, Ground
44	653035	Clip, Cord Plug
45	1113748	Wiring Harness, Unit Compartment
46	1113039	Stop

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")

876764 Valve, Access (3/16")

Following Parts Not Illustrated (Optional Parts Only)

4318419	Top Grille Trim Kit (8")
4318418	Top Grille Trim Kit (7-1/2")
4210570	Front Panel Kit (White)
4210569	Front Panel Kit (Black)
4211160	Front Panel Kit (Almond)
4210594	Front Panel Kit (Stainless Steel)


Black Acrylic Static Cleaner Part No. 978849

LITERATURE PARTS

LIT2000492	Installation Instructions
LIT1113982	Use & Care Guide
LIT2000144	Energy Label
LIT2000936	Service & Wiring Sheet
LIT628107	Modular Icemaker Service Sheet
LIT4361172	Parts List

# LOWER UNIT AND TUBE PARTS


For Model: KSSS42DWX02



1	2000528	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw, 8 x 1/2
4	1113293	Tube, Connect (Suction)
5	1113209	Tube, Connect (Discharge)
6	1113296	Tube, Flow Divider (2)
7	1113292	Valve, Fluid Control
8	1113294	Tube, Connect (Drier)
9	1113061	Heater, Drain Pan
10	1113062	Hanger, Heater
11	1113105	Bracket, Heater
12	487534	Screw, 8 x 1
13	1113256	Tube, Discharge
14	1113057	Sleeve
15	1113109	Heat Exchanger
16	1113041	Evaporator
17	2000631	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	549419	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	1112713	Clip, Connector
22	1113070	Guard, Hook-Up
23	851095	Strap (7)
24	488946	Clamp, Wiring
25	1113208	Drain Pan
26		Bracket, Drain Pan
	1113206	(L.H.)
	1113207	(R.H.)
28	934011	Clip, Water Tube
29	1112444	Wiring Harness, Water Valve
30	1113384	Tube, Connect (Suction)
31	1113297	Tube (2)
32	1113096	Tube, Condenser Inlet

# AIR FLOW AND RESERVOIR PARTS

For Model: KSSS42DWX02




1	945523	Fan Motor
2	992953	Compression Ring
3	992920	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw, 8 x 1/2
8	538449	Grommet, Screw
9	488500	Screw, Ground
11	1112529	Baffle, Evap.
12	2001257	Channel, Wiring
14	1111212	Scroll, Fan (Also Order Item 15)
15	1112976	Shield, Scroll
16	488772	Screw, 8 x 1/2
17	2000056	Assembly, Air Duct
18	2000048	Air Deflector, Icemaker
19	1112870	Cup, Motor
20	1112883	Shield
21	1112871	Fastener (3)
22	1112869	Gasket, Air Baffle
23	1113942	Cover, Air Outlet
24	488748	Screw, 8-32 x 1-1/2
25	2000486	Cover, Evaporator
26	1112565	Connector, Meat Pan Duct
27	487539	Screw, 8 x 1/2
28	1112840	Baffle, Evaporator
29	1112852	Diffuser, Air Duct
30	839912	Reservior, Water
31	2001259	Water Tube (Inlet)
32	841707	Insert, Tube
33	488819	"O" Ring Seal
34	488795	Compression Nut
35	1112875	Assembly, Air Baffle
36	1113147	Insulation, Air Diffuser
37	487539	Screw
38	1112878	Cover, Air Diffuser
39	489174	Screw, 8 x 2
40	488775	Screw
41	1112265	Tube, Meat Pan
43	2001260	Water Tube (Outlet)
44	488248	Screw, 8 x 3/4



# ICEMAKER PARTS


For Model: KSSS42DWX02



1	489084	Screw, 8 x 1/2
2	1112845	Fitting, Water Tube
3	488878	Clamp, Tube
4	841707	Insert, Tube
5	628379	Clip, Fuse
6	836074	Dampener
7	1112956	Tube, Water
8	1106508	Seal Gasket
9	488645	Screw, 8 x 1/2 (2)
10	1113103	Valve, Solenoid
11	627018	Nut, Compression
12	227991	Connector, Wire
14	488292	Washer
15	1113106	Tube, Inlet Valve
16	1113066	Clamp Tube
17	537588	Nut, Valve
18	628355	Cover
19	487294	Screw, 8-32 x 3/8 (2)
20	628228	Mold & Heater (Also Order 542638 Silicone Grease)
21	628258	Motor
22	628356	Cup, Water Fill
23	627843	Ejector
24	627788	Ice Striper
25	627790	Support
26	627796	Retainer Thermostat (2)
27	627985	Thermostat (Also Order 542639 Cement Alumilastic)
28	489322	Screw, 10-32 x 49/64
29	628332	Module Assembly
30	489276	Screw
31	627913	Shut Off Arm
32	1113403	Harness, Wiring
33	627915	Bracket
34	489365	Screw, 8-32 x 27/64
35	628366	Module Assembly (Includes Items 21, 25, 28, 29, 30 & 41)
36	1112847	Tube Clamp (4)
38	488794	"O" Ring
39	488819	"O" Ring
41	489136	Screw, (2) 3-24 x 3/8
43	486194	Screw, 8 x 1/2
44	488795	Compression Nut
100	4211173	Icemaker

# TOP GRILLE AND UNIT COVER PARTS

For Model: KSSS42DWX02



1	1113867	Grille, Frame Assembly
2	1113864	Decorative Panel Assembly
3	1113355	Back Up Panel
9	2000932	Top Grille Assembly
10	1113490	Cover, Unit
11	486194	Screw
12	1113300	Cover, Component Assembly